Zebra 2D USB and Bluetooth Scanners

Setup/Reset Sequence

1. Scan **Set Factory Defaults.**

✂ ┄┄

2. Scan **Add an Enter Key**.

✂ ┄┄

Note: You may have to perform the entire sequence more than once to reset the Zebra 2D USB and Bluetooth Barcode Scanners. If the reset does not resolve scanner performance issues, please contact Exatouch Tech Support at 1-800-966-5520 – Option 3, or go to help.exatouch.com.