


# DataLogic Magellan In-Counter Scale/Scanner

## Setup/Reset Sequence for In-Counter Scale/Scanner

### 1. Scan **Return to Factory Settings**



RETURN TO FACTORY SETTINGS



### 2. Scan **UPC-E Check Digit Enable**

UPC-E check Digit Enable



### 3. Scan **UPC-A Check Digit Transmit**

UPC-A Check Digit Transmit



#### 4. Scan **EAN-13 Check Digit Enable**

EAN-13 Check Digit Enable



#### 5. Scan **Enable EAN-8 Check Character**

Enable EAN-8 Check Character




#### 6. Scan **Code 39 Label ID = B - 4 byte**

Code 39 Label ID = B - 4 byte



## Enable Sequence for Remote Display

1. Scan **Enter/Exit Programming Mode**.



Enter/Exit Programming Mode




2. Scan **Remote Display Enable**.



Remote Display = Enable



3. Re-scan **Enter/Exit Programming Mode**.



Enter/Exit Programming Mode



## Disable Sequence for Remote Display

1. Scan **Enter/Exit Programming Mode**.



Enter/Exit Programming Mode




2. Scan **Remote Display Disable**.



Remote Display = Disable



3. Re-scan **Enter/Exit Programming Mode**.



Enter/Exit Programming Mode



**Note:** You may have to perform the entire sequence more than once to reset the scanner or remote display. If the reset does not resolve performance issues, please contact Exatouch Tech Support at 1-800-966-5520 – Option 3, or go to [help.exatouch.com](https://help.exatouch.com).